



Equation (SURVEY POT. 100+00) [SB] POT. 10+54.25 = APT. 22' LT. POT. 100+12.5231

Equation (SURVEY POT. 100+00) [NB] POT. 0+54.25 = APT. 24' RT. POT. 99+91.86

26' LT. (SURVEY PC. 97+09.01) BEG. CONST. STA. [SB] PC. 97+09.01

12' RT. (SURVEY PC. 97+09.01) BEG. CONST. STA. [NB] PC. 97+09.01

Std. Survey 97+00 - Std. Survey 2+78