




LAYOUT SHOWING WORKING POINTS



TYPICAL CORNER DETAILS
SCALE: 3/4" = 1'-0"



SUPERELEVATION CHART



CROSS-SECTION SHOWING LAKE SLOPES

POINT	DIMENSIONS BETWEEN WORKING POINTS						ELEVATIONS					
	A	B	C	D	E	F	TOP OF SLAB BR. SEAT	SLAB TO BR. SEAT	BRIDGE SEAT	POINT		
A	120+38.42	67.00	20.22	63.02	65.35	895.62	4.62	891.00	A			
B	171+05.42	76.32	20.22	69.32	74.47	894.30	4.62	889.68	B			
C	180+31.50	76.32	20.22	67.00	63.02	895.34	4.62	890.72	C			
D	180+98.50	76.32	20.22	76.32	894.22	4.62	889.60	D				
E	180+24.58	67.00	67.00	67.00	895.00	4.62	890.38	E				
F	180+91.58	67.00	67.00	67.00	894.03	4.62	889.41	F				

TOP OF SLAB TO BRIDGE SEAT	
SLAB	W. ABUT. E. ABUT.
STOOL	9" 9"
BEAM	3'-4" 3'-4"
BEARING	3 1/2" 3 1/2"
TOTAL	4'-7 1/2" 4'-7 1/2"